



# TRIANGLE

## ELECTRONIC CONTROLS

### CALIBRATION PROCEDURE

<b>CUSTOMER:</b>	<b>TRIANGLE ELECTRONIC CONTROLS LTD</b>	<b>PRODUCT:</b>	<b>PANEL MOUNT AUTOSAT ALARM</b>
<b>DATE:</b>	<b>21/08/09</b>	<b>ISSUE:</b>	<b>2</b>
<b>PROCEDURE NUMBER:</b>	<b>CL0031</b>	<b>APPROVED:</b>	<b>DJP</b>

- 1) WHILST PRESSING AND HOLDING THE MUTE BUTTON POWER THE UNIT UP, WHEN AN AUDIO BEEP SOUNDS RELEASE THE MUTE BUTTON.
- 2) THE RED AND GREEN LEDS WILL ALTERNATE OFF AND ON TO SHOW THE UNIT IS IN CALIBRATION MODE.
- 3) LEAVE THE UNIT FOR 15 MINS TO ALLOW THE SENSOR TO REACH OPERATING TEMPERATURE.
- 4) PRESS THE MUTE BUTTON ONCE, THE LED WILL STOP ALTERNATING AND THE GREEN LED'S WILL LIGHT.
- 5) THE UNIT IS NOW CALIBRATED.

### CONNECTIONS

PL1	GAS SENSOR CABLE
PL2	VOLT FREE
PIN 1&2	NO
PIN 2&3	NC

**NB: THE AUDIO ALARM DOES NOT ARM FOR 5 MINUTES AFTER INITIAL POWER UP**